

OPERATING OF THE VALVES IN DIFFERENT CAR MODES

Car mode	Gear lever	Button on console	Active X crossing valve	Back valves
Comfort	P or N	OFF	Open (silent)	Closed
Comfort	R,1,2...7	OFF	Open (silent)	Gear 1,2,3 and 4: Throttle up to 40% : Closed Throttle above 40%: Closed, then open fully above 3200 rpm
Sport	P or N	OFF	Open (silent)	Open
Sport	R,1,2...7	OFF	Open (silent)	Throttle up to 70%: Closed, then open above 2500 rpm Throttle above 70%: Open directly
Sport+	P or N	ON	Open (silent) below 1000 rpm, above closed (loud)	Open
Sport+	R,1,2...7	ON	Open (silent) below 1000 rpm, above closed (loud)	Open
Race	P or N	ON	Open (silent) below 1000 rpm, above closed (loud)	Open
Race	R,1,2...7	ON	Open (silent) below 1000 rpm, above closed (loud)	Open

Use your Exhaust button or Akrapovič Keyfob, to switch between different Sound Modes:



LIGHT OFF / (white Akrapovič keyfob light)

Open

LIGHT ON red / (red Akrapovič keyfob light)

Closed